

SLU4 Slot Sensor



Quick Start Guide

Ultrasonic Label Sensors for Detection of Clear Labels

This guide is designed to help you set up and install the SLU4 Slot Sensor. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at www.bannerengineering.com. Search for p/n 230091 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.




WARNING:

- **Do not use this device for personnel protection**
- Using this device for personnel protection could result in serious injury or death.
- This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A device failure or malfunction can cause either an energized (on) or de-energized (off) output condition.

Models

Model	Supply Voltage	Output Type	Connection
SLU4-PN-2M	12 V DC to 30 V DC	Bipolar NPN/PNP	1.8 m (6 ft) unterminated 5-wire PVC cable
SLU4-PN-Q8			Integral 5-pin M12 male quick-disconnect connector
SLU4-PN-Q7		Selectable NPN or PNP	Integral 4-pin M8 male quick-disconnect connector
SLU4-BM-Q7			

Features and Indicators



1. Output indicator
2. Display
3. (GAP/2PT/DYN)(+)
4. (TEACH)(SELECT)
5. (MODE)(-)


Output Indicator

- Amber LED illuminates when outputs are ON
- Flashes when short circuit or overload detected

Display

Use the display to view menu options and other information.

Figure 1. Display in Run Mode



1. Signal strength
2. Contrast indicator (0 to 9)
3. Threshold number
4. Output in gap or on label
5. Button lock or unlock
6. Auto adjust on/off (AUTO)

Buttons

Use the sensor buttons to program the sensor.

(GAP/2PT/DYN)(+)

- Press and hold for 2 seconds to access and select different TEACH methods
- Press to increase the contrast threshold value
- Scroll through settings in the menu
- Manually adjust the threshold number while in Run mode

(TEACH)(SELECT)

- Press and hold for 2 seconds to initiate the TEACH process
- Select settings in MENU options

(MODE)(-)

- Press and hold for 2 seconds to access the menu
- Scroll through settings in the menu
- Manually adjust the threshold number while in Run mode



Installation

Mount the Sensor

Mount the SLU4 directly and securely using the clearance holes on the side of the sensor (bolts not included).

To lessen the effects of web flutter, position the bottom fork of the sensor slightly above the path of the web so that the web can glide over the bottom of the fork with slight tension.

Wiring

Figure 2. M8 Models—bimodal with remote input




Figure 3. M8 model, bipolar





Figure 4. M8 Male Connector



The black wire is selectable NPN or PNP via the menu. This selection causes the remote input to be active low or active high.

Figure 5. M12 and cabled models—bipolar with remote input





Figure 6. M12 Male Connector



Sensor Setup

Use the following images and instructions to program the sensor for use.


The default TEACH mode is Gap TEACH.

Gap TEACH

The sensor sets a threshold based on the gap between two labels.


1. Place the label web so that it is centered on the arrow.

Figure 7. Align Label to Arrow



2. Position the gap between the labels in the center of the sensor using the alignment line as shown. When viewing from the top of the sensor, use the output LED to center the gap between the labels.

Figure 8. Align Gap to Line





Note: For a simpler TEACH, remove one label to create a larger gap.

- Place label webbing so that it slides along the bottom of the sensor gap plate. This ensures a more consistent setup and performance.
- Press and hold the **TEACH** button for 2 seconds. The display shows "Gap Set", then returns to Run mode.

The + and - buttons can be used to manually fine tune the sensor to the application.

Sensor Menu

Access the menu from run mode by pressing and holding **MODE** for 2 seconds.

Use + and - buttons to navigate through the menu. Press **SELECT** to select a menu option and access the submenus. Use + and - to navigate through the submenus. Press **SELECT** to select a submenu option and return to the top menu or press and hold **SELECT** for longer than 2 seconds to select a submenu option and return immediately to run mode.



To exit Setup mode and return to Run mode, navigate to End and press **SELECT**.


The following are menu options:


Adaptive Tracking

Evaluates signal levels and makes automatic adjustments to keep the sensor in optimum response levels.

Output Mode

Change from GAP () to LABEL (). GAP means the output will be on when the label is not present under the transducer. LABEL means the output will be on when the label is under the transducer.

 = Outputs on the Label

 = Outputs in the Gap

Display Orientation

Toggles the orientation of the display.

Timer Mode

Selects the output timing delay to be set:


Off Delay—Outputs stay on for set time after duration of input.

On Delay—Outputs turn on when input exceeds set time.

One Shot—Outputs turn on for set time when triggered by input.

Debounce—Output changes immediately when a change in detect state occurs. Then, a timer prevents the output from switching again until the timer expires. This behavior occurs on both the leading and trailing edges of the object.

Figure 9. Output Timing Delays




Timer Value

Sets the delay timer. This menu item is available only if a Timer Mode has been selected. The range is 1 ms to 9999 ms.

Button Lockout

Locks the sensor for tamper-free operation.

The sensor can be taught if it is locked. To unlock the sensor, toggle from Lock () to Unlock (no symbol).

Scope

Allows the operator to visually inspect the current setup for repeatability. The sensor scope also reveals any nominal setup issues or sensitivities to label or gap thickness changes. To shorten the time between signals, press +. To lengthen the time between signals, press -.

Input Active (SLU4-PN-2M and SLU4-PN-Q8 models only)

Sets the remote input to either Active High or Active Low to dictate the type of signal needed to program the sensor remotely. For more details, see [Remote Input](#) on page 4.

Input/Output (SLU4-BM-Q7 model only)

Sets the output to either NPN or PNP. Also sets the remote input to either Active High or Active Low to dictate the type of signal needed to program the sensor remotely. For more details, see [Remote Input](#) on page 4.

End

Returns to run mode.

Factory Reset

Resets the sensor to factory defaults.

Remote Input

Use the remote input to program the sensor remotely.

The remote input provides limited programming options. The remote input is either Active High (PNP) or Active Low (NPN) depending on the Input Active setting. For Active High (PNP), connect the white wire to 24 V DC with a remote switch connected between the wire and 24 V DC. For Active Low, connect the white wire to ground (0 V DC) with a remote switch connected between the wire and ground. Pulse the remote input according to the diagram and the instructions provided in this manual.

The length of the individual programming pulses is equal to the value **T: 0.04 seconds ≤ T ≤ 0.4 seconds**.

Remote Input Signals

Note: Waveforms shown correspond to PNP input mode.

Figure 10. Gap Set



Pulse once, 40 ms to 400 ms.

Figure 11. Label Set



Pulse twice, 40 ms to 400 ms, with 40 ms to 400 ms idle time between pulses.

Figure 12. Dynamic Set



Hold the remote input on for more than 750 ms, while pulling the labels and gaps through the sensor, then release the remote input line. The sensor returns to Run mode.

Specifications**Supply Voltage and Current**

12 V DC to 30 V DC
Polarity Protected



Note: For use in Class 2 circuits

95 mA at 12 V DC, 45 mA at 30 V DC

Digital Outputs

(1) NPN and (1) PNP open collector output 150mA maximum; <2 V residual voltage
On SLU4-BM-Q7, NPN & PNP are user-selectable
Protected against output short-circuit

Remote TEACH Input

Momentary sinking or sourcing input; 1.2 mA maximum; software selectable

Hysteresis

Dynamic, adjusted by TEACH

Response Time

200 μs

Repeatability

125 μs

Threshold Set

1-Point, 2-Point, or Dynamic TEACH; manually or remotely

Threshold Adjust

Manual or AUTO adjust

Output Timers

On Delay, Off Delay, One Shot, or Debounce

Slot Width

4 mm

Indicators

Display: Includes contrast indicator, numerical display, set point and trigger point, and all sensor options and modes
Amber LED output indicator: Illuminates when the sensor's output transistors are ON



Note: Note: If output LED flashes on power up, a short circuit condition exists.

Construction

Chemical resistant, high impact aluminum housing
Conforms to heavy industry grade CE requirements

Connection

Integral 5-pin M12 male quick-disconnect connector, Integral 4-pin M8 male quick-disconnect connector, or 1.8 m (6 ft) unterminated 5-wire PVC cable, depending on model

Environmental Rating

NEMA 4X, NEMA 6P, and IP65

Ambient Temperature

+4 °C to +50 °C (+39 °F to +122 °F)

Certifications

RoHS compliant



Banner Engineering Europe Park
Lane, Culliganlaan 2F bus 3, 1831
Diegem, BELGIUM

Turck Banner LTD Blenheim House,
Blenheim Court, Wickford, Essex
SS11 8YT, Great Britain

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. **IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.**

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.