# WORLD-BEAM® QS18 Series Sensor



# Quick Start Guide

Miniature Self-Contained Photoelectric Sensors In Universal-Mount Housing

This guide is designed to help you set up and install the WORLD-BEAM® QS18. For complete information on programming, performance, troubleshooting, dimensions, and accessories, please refer to the Instruction Manual at www.bannerengineering.com. Search for p/n 197052 to view the Instruction Manual. Use of this document assumes familiarity with pertinent industry standards and practices.



## WARNING: Not To Be Used for Personnel Protection

Never use this device as a sensing device for personnel protection. Doing so could lead to serious injury or death. This device does not include the self-checking redundant circuitry necessary to allow its use in personnel safety applications. A sensor failure or malfunction can cause either an energized or de-energized sensor output condition.



## Models

Model <sup>1</sup>	Sensing Mode		Output Type	Model <sup>1</sup>	Sensing Mode		Output Type
QS186E				QS18VN6DB	450 mm (18 in)		NPN
QS186EV	20 m (66 ft) Opposed		Emitter	QS18VP6DB	Diffuse		PNP
QS18VN6R		OPPOSED	NPN	QS18VN6DL	600 mm (23.6 in) Diffuse	DIFFUSE	NPN
QS18VP6R			PNP	QS18VP6DL			PNP
				QS18VN6DVS			NPN
				QS18VP6DVS	250 mm (10 in) Diffuse Visible red	DIFFUSE	PNP
QS186EB			Emitter	-			
QS18VN6RB			NPN	QS18VN6W		DIVERGENT	NPN
QS18VP6RB	3 m (10 ft) Opposed	OPPOSED	PNP	QS18VP6W	100 mm (4 in) Divergent Diffuse		PNP
QS18VN6LP			NPN	QS18VN6FF50			NPN
QS18VP6LP	3.5 m (12 ft) Polarized Retro	P	PNP	QS18VN6FF50	50 mm (2 in) Fixed-Field		PNP
				QS18VP6FF30			NPN
				QS18VP6FF100	100 mm (4 in) Fixed-Field		PNP
		POLAR RETRO		QSTOVFOFFTUU			FINE
QS18VN6LV			NPN	QS18VP6FF125	F125 125 mm (5 in) Fixed-Field FixeD-FIELD		PNP
	6.5 m (21 ft) Non-Polarized Retro		PNP	QS18VN6FF150	150 mm (6 in)	)	NPN
				QS18VP6FF150	Fixed-Field		PNP
QS18VP6LV				QS18VN6FP	000 mm (0.7 in)		NPN
					220 mm (8.7 in) Individual (Opposed) 60 mm (2.4 in) Bifurcated (Diffuse) Range specified using 1.5 mm plastic fiber optics		PNP
QS18VN6CV15			NPN	QS18VP6FP			
QS18VP6CV15	16 mm (0.63 in) Convergent	CONVERGENT VISIBLE RED	PNP	QS18VN6F		PLASTIC FIBER	NPN
					500 mm (20 in) Individual (Opposed) 38 mm (1.5 in) Bifurcated (Diffuse) Range specified using 3.2 mm plastic fiber optics		
				QS18VP6F			
							PNP
QS18VN6CV45	_		NPN			GLASS FIBER	FINE
QS18VP6CV45	43 mm (1.7 in) Convergent	CONVERGENT VISIBLE RED	PNP				
QS18VN6D			NPN	1			
QS18VP6D	450 mm (18 in) Diffuse	DIFFUSE	PNP	1			

<sup>1</sup> Integral 2 m (6.5 ft) unterminated cable models are listed.

<sup>•</sup> To order the 9 m (30 ft) PVC cable model, add the suffix "W/30" to the cabled model number. For example, QS186E W/30.

<sup>•</sup> To order the 4-pin M12/Euro-style integral quick disconnect model, add the suffix "Q8" to the model number. For example, QS186EQ8.


To order the 150 mm (6 in) PVC cable model with a 4-pin M12/Euro-style quick disconnect, add the suffix "Q5" to the model number. For example, QS186EQ5.

<sup>•</sup> To order the 4-pin M8/Pico-style integral quick disconnect model, add the suffix "Q7" to the model number. For example, QS186EQ7.

<sup>•</sup> To order the 150 mm (6 in) PVC cable model with a 4-pin M8/Pico-style quick disconnect, add the suffix "Q" to the model number. For example, QS186EQ.

## Wiring Diagrams


## QS18 with NPN Outputs



4-pin M12/Euro-style Models (Male)



QS18 with PNP Outputs



### 4-pin M8/Pico-style Models (Male)



#### **QS18 Emitters**

brown + 10–30 V DC blue –

#### Key



4 = Black

## Specifications

#### Supply Voltage

10 V dc to 30 V dc (10% maximum ripple) at less than 25 mA, exclusive of load

Protected against reverse polarity and transient voltages

### Light Source

Glass Fiber Optic, Opposed and Diffuse mode models: Infrared, 940 nm Plastic Fiber Optic, Retroreflective, Convergent models: Visible red, 660 nm Fixed-Field and DVS models: Visible red, 630 nm

#### Adjustments

Glass Fiber Optic, Plastic Fiber Optic, Convergent, Diffuse, and Retroreflective mode models (only): Single-turn sensitivity (Gain) adjustment potentiometer

#### Indicators

2 LED indicators on sensor top Green: Power on Amber: Light sensed

Amber flashing: Marginal excess gain (1 to 1.5 times excess gain)

#### Certifications



#### **Required Overcurrent Protection**



**WARNING:** Electrical connections must be made by qualified personnel in accordance with local and national electrical codes and regulations.

Overcurrent protection is required to be provided by end product application per the supplied table.

Overcurrent protection may be provided with external fusing or via Current Limiting, Class 2 Power Supply.

Supply wiring leads < 24 AWG shall not be spliced.

For additional product support, go to www.bannerengineering.com.

Supply Wiring (AWG)	Required Overcurrent Protection (Amps)		
20	5.0		
22	3.0		
24	2.0		
26	1.0		
28	0.8		
30	0.5		

#### Repeatability

Opposed Mode: 100 microseconds DVS, DL and FF Modes: 90 microseconds All Other Modes: 150 microseconds

#### Output Configuration

Solid-state complementary (SPDT): NPN or PNP (current sinking or sourcing), depending on model; Rating: 100 mA maximum each output at 25  $^{\circ}$ C DVS, DL and FF Modes ON-state Saturation Voltage: less than 1.5 V at 10 mA; less than 3 V at 100 mA All Other Modes: ON-state Saturation Voltage: less than 1 V at 10 mA; less than 1.5 V at 100 mA

Protected against false pulse on power-up and continuous overload or short circuit of outputs

#### **Output Response**

Opposed Mode: 750 microseconds ON; 375 microseconds OFF DVS, FF and DL Modes: 850 microseconds ON/OFF All Other Modes: 600 microseconds ON/OFF 100 millisecond delay on power-up; outputs do not conduct during this time

## Construction

#### ABS housing

3 mm mounting hardware included

Connections

2 m (6.5 ft) 4-wire PVC cable; 9 m (30 ft) 4-wire PVC cable; 4-pin M8/Picostyle or M12/Euro-style QD; or 150 mm (6 in) cable with a 4-pin M8/Picostyle or M12/Euro-style QD, depending on model

#### Environmental

IEC IP67; NEMA 6

#### Operating Conditions

-20 °C to +70 °C (-4 °F to +158 °F) 95% at +50 °C maximum relative humidity (non-condensing)


#### Vibration and Mechanical Shock

All models meet MIL-STD-202F, Method 201A (Vibration: 10 Hz to 60 Hz maximum, 0.06 inch (1.52 mm) double amplitude, 10G maximum acceleration) requirements. Also meets IEC 60947-5-2 (Shock: 30G 11 ms duration, half sine wave) requirements.

**Note:** For performance specifications of the FF50 and FF100 models built prior to date code 17090, refer to document p/n 63908.

### Dimensions

#### All measurements are listed in millimeters [inches], unless noted otherwise.



## Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE. This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications phane the product is dontified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

