

Single Output, Linear



Selection Guide (Partial)

See pages 10 — 11 for dimension drawings

Single Output Models								
Model	Case	Output	Model	Case	Output	Model	Case	Output
2 VOLTS BVA-2AS3 BVA-2BS6 BVA-2DS12 BVA-2ES18	AS BS DS ES	2V @ 3A 2V @ 6A 2V @ 12A 2V @ 18A	12 VOLTS BVA-12AS0.9 BVA-12AS1.7 BVA-12BS3.4 BVA-12CS5.1 BVA-12DS6.8 BVA-12ES10.2 BVA-12FS16	AS AS BS CS DS ES FS	12V @ 0.9A 12V @ 1.7A 12V @ 3.4A 12V @ 5.1A 12V @ 6.8A 12V @ 10.2A 12V @ 16A	28 VOLTS BVA-28AS0.5 BVA-28AS1 BVA-28BS2 BVA-28CS3 BVA-28DS4 BVA-28ES6 BVA-28FS10	AS AS BS CS DS ES FS	28V @ 1.5A 28V @ 1A 28V @ 2A 28V @ 3A 28V @ 4A 28V @ 6A 28V @ 10A
5 VOLTS BVA-5AS1.5-OVP BVA-5AS3-OVP BVA-5BS6-OVP BVA-5CS9-OVP BVA-5DS12-OVP BVA-5ES18-OVP BVA-5FS25-OVP	AS AS BS CS DS ES FS	5V @ 1.5A 5V @ 3A 5V @ 6A 5V @ 9A 5V @ 12A 5V @ 18A 5V @ 25A	15 VOLTS BVA-15AS0.9 BVA-15AS1.5 BVA-15BS3 BVA-15CS4.5 BVA-15DS6 BVA-15ES9 BVA-15FS15	AS AS BS CS DS ES FS	15V @ 0.9A 15V @ 1.5A 15V @ 3A 15V @ 4.5A 15V @ 6A 15V @ 9A 15V @ 15A	48 VOLTS BVA-48AS0.5 BVA-48BS1 BVA-48DS3 BVA-48ES4 BVA-48FS8	AS BS DS ES FS	48V @ 0.5A 48V @ 1A 48V @ 3A 48V @ 4A 48V @ 8A
7 VOLTS BVA-7AS1 BVA-7AS2 BVA-7BS4 BVA-7CS6 BVA-7DS8 BVA-7ES12.5 BVA-7FS17.5	AS AS BS CS DS ES FS	7V @ 1A 7V @ 2A 7V @ 4A 7V @ 6A 7V @ 8A 7V @ 12.5A 7V @ 17.5A	18 VOLTS BVA-18AS1.5 BVA-18BS3 BVA-18CS4.5 BVA-18DS6 BVA-18ES9 BVA-18FS15	AS BS CS DS ES FS	18V @ 1.5A 18V @ 3A 18V @ 4.5A 18V @ 6A 18V @ 9A 18V @ 15A	Ask for specials. Custom variations quoted and shipped promptly *Unregulated		
10 VOLTS BVA-10AS1.7 BVA-10BS3.4 BVA-10CS5.1 BVA-10DS6.8 BVA-10ES10.2 BVA-10FS16	AS BS CS DS ES FS	10V @ 1.7A 10V @ 3.4A 10V @ 5.1A 10V @ 6.8A 10V @ 10.2A 10V @ 16A	24 VOLTS BVA-24AS0.5 BVA-24AS1.2 BVA-24BS2.4 BVA-24CS3.6 BVA-24DS4.8 BVA-24ES7.2 BVA-24FS12 BVA-24GS24 BVA-24MIL8/17	AS AS BS CS DS ES FS GS -	24V @ 0.5A 24V @ 1.2A 24V @ 2.4A 24V @ 3.6A 24V @ 4.8A 24V @ 7.2A 24V @ 12A 24V @ 24A 24V @ 8A 24V @ 17A*			

Options:

Screw Terminals (T): Solder terminals standard. Add "T" for screw terminals, 20A/300V

Overvoltage Protection (OVP): OVP is standard on all 5V main outputs. Add "OVP" to part number for individual OVP module on other models up to 36VDC outputs.

Mounting Spacers (S): For mounting spacers on any one surface add "S" to part number. Not available on FS and GS case sizes.

Input Fuse (F): For input fuse and fuse holder add "F" to part number.

Line Cord (C): For input line cord add "C" to part number.

Surge Absorber (M): Input MOV 150V for line voltage of 100-117VAC; and 320V for line voltage of 220-240VAC