INTRODUCTION
Characteristics
Specification
Interface Definitions
Installation Method
Demo Program
FAQ
More Documents

SKU:SEN0609

INTRODUCTION

The C4001mWaveRadar is a 24GHz millimeter-wave presence sensor utilizes a wavelength signal of 24GHz. It has a detection range of 500 horizontally, with a presence detection range of 16 meters and a motion detection and distance measurement range of 12 meters.

Human Detection

Compared to other types of presence sensors such as infrared, ultrasonic, and camera sensors, the C4001mWaveRadar millimeter-wave presence sensor has the advantage of detecting the smallest micro-motions of human body. It also has a relatively strong anti-interference capability. It can penetrate thin materials to sense such as temperature changes, variations in ambient light, and color changes. Even when a person is sitting still, standing or in motion, the sensor can quickly and sensitively detect their presence.

	Millimeter-wave Presence Sensor	Infrared Sensor
Sensing Principle	TOF radar principle + Doppler radar principle (micro-motion detection)	Pyroelectric infrared sensing principle (infrared radiation)
Motion Sensitivity	Can detect presence, slight movement, and motion of human body	Can only detect motion and does not range slight movement of human body
Sensing Range	Can be adjusted to different sensing distances	Sensing range cannot be adjusted
Environmental Temperature Impact	Not affected by environmental temperature	Sensitivity when ambient temperature is close to human body temperature
Application Environment	Not affected by heat sources, light sources, air flow	Susceptible to heat source and air flow
Penetration Ability	Can penetrate fabrics, plastics, glass, and other insulating materials	Can only penetrate some transparent plastics
Distance Measurement Support	Yes	No

Distance and velocity detection

The C4001mWaveRadar millimeter-wave presence sensor utilizes Frequency Modulated Continuous Wave (FMCW) modulation for distance and velocity speed measurement. It has a maximum measurement range of 25 meters for distance and a speed measurement range of 0.1 to 10 meters per second.

FMCW is a radar system based on the principle of frequency modulation. It continuously emits a series of frequency-modulated signals and receives the reflected signals. By analyzing the frequency difference between the transmitted and received signals, it can accurately measure the distance of objects. By utilizing the Doppler effect, FMCW can also measure the velocity of objects. It continuously measures the distance of objects. By utilizing the Doppler effect, FMCW can also measure the velocity of objects. By analyzing the frequency shift between the transmitted and received signals, it can accurately measure the distance of objects. Additionally, FMCW can measure the velocity of objects by detecting the Doppler effect. This enables it to provide real-time information on the object's speed and direction of movement.

What is a millimeter-wave radar sensor?

Millimeter-wave radar technology is a non-contact sensing technology used to detect objects and provide information about their distance, speed, and angle (in the case of human). Its operating principle involves emitting millimeter-wave signals and receiving the reflected signals. The wavelength of millimeter waves is between 1 and 10 millimeters, corresponding to frequencies between 30 GHz and 300 GHz. Also known as the millimeter (mm) range.

Characteristics

- Human detection: Detection range up to 16 meters and motion detection range up to 25 meters.
- Distance detection: Range from 0.2 meters to 25 meters.
- Velocity detection: Range from 0.1 meters per second to 10 meters per second.
- Strong anti-interference capability, unaffected by snow, rain, temperature, humidity, dust, light, noise.
- High and low level output control IO ports.
- Small size, easy to integrate.
- Small size, easy to integrate.

Specification

- Operating voltage: 3.3/5V
- Maximum detection range: 25m
- Beam angle: 120°*60°
- Modulation mode: FMCW
- Operating frequency: 24GHz
- Operating temperature: -40~85℃
- Baud rate: 9600
- Size: 20*20mm

Interface Definitions

Definition	Explanation
VIN	Power supply
GND	Ground
RX	Sensor serial port receive
TX	Sensor serial port transmit
OUT	Voltage output

Installation Method

The millimeter-wave human body sensor is sensitive to the installation method, and improper installation can affect the performance and functionality of the sensor. The commonly used installation methods for the millimeter-wave human body sensor include horizontal installation, horizontal installation, and mounted installation.

Top Installation



Bottom Installation



Horizontal Installation



Demo Program

There is information retrieval.

Preparation

- Hardware
  - C4001 Millimeter Wave Presence Sensor 12m
  - Arduino Uno
- Software

Arduino IDE, Click to download Arduino IDE

DFRobot_C4001 library, Click to download the DFRobot_C4001 library.

Wiring diagram

Mcr60use	Arduino Uno
VIN	5V
GND	GND
RX	D5
TX	D4

Sample code

Please copy the following code and upload it to your Arduino IDE.

```
/*!
 * @file  motionSensor.ino
 * @brief  Example of radar detecting whether an object is m
 * @copyright  Copyright (c) 2010 DFRobot Co.Ltd (http://www.d
 * @license  The MIT License (MIT)
 * @author  [Arsen](Arsen.Lee@dfrobot.com)
 * @version  V1.0
 * @date  2024-03-01
 * @url  https://github.com/DFRobot/DFRobot_C4001
 */
#include "DFRobot_C4001.h"

//Define I2C_COMMUNICATION  //Uncomment this line for communication, but

#ifdef I2C_COMMUNICATION
  /*!
   * @brief ADDR_0 = 0x2A   default I2C address
   * @brief ADDR_1 = 0x2B
   */
  DFRobot_C4001_I2C radar(&Wire, /*I2C address*/ 0x2A);
#else
  /*!
   * @brief Board |          RX1          | Level shifting
   *        UNO   |          D10          |
   *        MEGA  |          D68          |
   *        M0    |          D1           |
   *        ESP32 |          D5           |
   *        M4    |          D7           |
   * @brief Use hardware serial for communication, the following two
   */
  DFRobot_C4001_UART radar(&Serial, /*baud rate*/ 9600, /*RX*/ D6, /*TX*/
#endif

void setup()
{
  Serial.begin(115200);
  while (!Serial);
  delay(1000);
  Serial.println("Device connected!");

  // pinMode(D6, INPUT);
  radar.setSensorMode(eSleepMode);

  //Serial.println(F("Radar parameter configuration"));
  data = radar.getDirection();
  Serial.print("Target direction : ");
  Serial.println(data);
  Serial.print("Work status : ");
  Serial.println(data.workStatus);

  // It is valid. | Invalid
  Serial.print("Work mode : ");
  Serial.println(data.workMode);

  // 0~9 Unit : 1 Unit survive
  // 10~15 Unit : 10 Unit survive
  Serial.print("Unit status : ");
  Serial.println(data.unitStatus);
  Serial.println();

  /*
   * Min detection range Minimum distance, unit +m, range 0.2
   * Max detection range Maximum distance, unit +m, range 0.2
   * Trig detection range Residence distance, unit +m, default
   */
  if(radar.setDetectionRange(/*minR*/0, /*max*/1000, /*trig*/0
    Serial.println("Set detection range successfully!");
  }

  // set trigger sensitivity 0 ~ 9
  if(radar.setTriggerSensitivity(5)){
    Serial.println("set trig sensitivity successfully!");
  }

  // set keep sensitivity 0 ~ 9
  if(radar.setKeepSensitivity(3)){
    Serial.println("set keep sensitivity successfully!");
  }

  /*
   * trig trigger delay, unit 0.01s, range 0~in (0.00)
   * Keep Residence the detection timeout, unit 0.01s, range 0.5
   */
  if(radar.setDelay(/*trig*/500, /*keep*/2000)){
    Serial.println("set delay successfully!");
  }

  // get configure params
  Serial.print("Trig sensitivity : ");
  Serial.println(radar.getTrigSensitivity());
  Serial.print("Keep sensitivity : ");
  Serial.println(radar.getKeepSensitivity());

  Serial.print("Min range : ");
  Serial.println(radar.getMinRange());
  Serial.print("Max range : ");
  Serial.println(radar.getMaxRange());
  Serial.print("Trig range : ");
  Serial.println(radar.getTrigRange());

  Serial.print("Keep time : ");
  Serial.println(radar.getKeepTime());

  Serial.print("Trig delay : ");
  Serial.println(radar.getTrigDelay());
}

void loop()
{
  // Determine whether the object is moving
  if(radar.motionDetection()){
    Serial.println("motion motion");
    Serial.println();
  }
  delay(100);
}
```

result



Distance speed acquisition

Preparation

- Hardware
  - C4001 Millimeter Wave Presence Sensor 12m
  - Arduino Uno
- Software

Arduino IDE, Click to download Arduino IDE

DFRobot_C4001 library, Click to download the DFRobot_C4001 library.

Wiring diagram

Mcr60use	Arduino Uno
VIN	5V
GND	GND
RX	D5
TX	D4

Sample code

Please copy the following code and upload it to your Arduino IDE.

```
/*!
 * @file  ATargetVelocity.ino
 * @brief  Example of radar ranging
 * @copyright  Copyright (c) 2010 DFRobot Co.Ltd (http://www.d
 * @license  The MIT License (MIT)
 * @author  [Arsen](Arsen.Lee@dfrobot.com)
 * @version  V1.0
 * @date  2024-03-01
 * @url  https://github.com/DFRobot/DFRobot_C4001
 */
#include "DFRobot_C4001.h"

//Define I2C_COMMUNICATION  //Uncomment this line for communication, but

#ifdef I2C_COMMUNICATION
  /*!
   * @brief ADDR_0 = 0x2A   default I2C address
   * @brief ADDR_1 = 0x2B
   */
  DFRobot_C4001_I2C radar(&Wire, /*I2C address*/ 0x2A);
#else
  /*!
   * @brief Board |          RX1          | Level shifting
   *        UNO   |          D10          |
   *        MEGA  |          D68          |
   *        M0    |          D1           |
   *        ESP32 |          D5           |
   *        M4    |          D7           |
   * @brief Use hardware serial for communication, the following two
   */
  DFRobot_C4001_UART radar(&Serial, /*baud rate*/ 9600, /*RX*/ D6, /*TX*/
#endif

void setup()
{
  Serial.begin(115200);
  while (!Serial);
  delay(1000);

  while(!radar.begin()){
    Serial.println("No devices !");
    delay(1000);
  }
  Serial.println("Device connected!");

  // Speed Mode
  radar.setSensorMode(eSpeedMode);

  //Serial.println(F("Radar parameter configuration"));
  data = radar.getDirection();
  Serial.print("Target direction : ");
  Serial.println(data);
  Serial.print("Work status : ");
  Serial.println(data.workStatus);

  // It is valid. | Invalid
  Serial.print("Work mode : ");
  Serial.println(data.workMode);

  // 0~9 Unit : 1 Unit survive
  // 10~15 Unit : 10 Unit survive
  Serial.print("Unit status : ");
  Serial.println(data.unitStatus);
  Serial.println();

  /*
   * Min detection range Minimum distance, unit +m, range 0.2
   * Max detection range Maximum distance, unit +m, range 0.2
   * Trig range Detection timeout, Elementless unit 0.01, def
   */
  if(radar.setDetectionRange(/*minR*/0, /*max*/1000, /*trig*/0
    Serial.println("Set detection range successfully!");
  }

  // set tracking Detection
  radar.setTrackingBoundaryMode();

  // get configure params
  Serial.print("Min range : ");
  Serial.println(radar.getMinRange());
  Serial.print("Max range : ");
  Serial.println(radar.getMaxRange());
  Serial.print("Threshold range : ");
  Serial.println(radar.getThreshold());
  Serial.print("Trig range : ");
  Serial.println(radar.getTrigRange());

  Serial.print("Keep time : ");
  Serial.println(radar.getKeepTime());
}

void loop()
{
  Serial.print("Target number : ");
  Serial.println(radar.getTargetNumber());  // Wait valid
  Serial.print("Target Speed : ");
  Serial.println(radar.getTargetSpeed());
  Serial.print("Target range : ");
  Serial.println(radar.getTargetRange());
  Serial.print("Target energy : ");
  Serial.println(radar.getTargetEnergy());
  Serial.println();
  delay(100);
}
```

result



FAQ

If you have any questions about using this product, please check the Comprehensive Guide to Smart Home Presence Detection | FAQ for that product for a corresponding solution.

And for any questions, ardoince.cn/ask/ is also there for the DFRobot Forum.

More Documents

SEN0609 Communication protocol.pdf

dimensional drawing

DFRobot purchase link in the online store